

OUTDOOR ROLL-UP SHADES: DIRECTIONS TO INSTALL, USE AND MAINTAIN

HOW TO INSTALL

1. Determine mounting height of panels.
Mark height of panel on the surface by stretching full length of panel to the top.
2. Mount L-bracket to support the wooden rod holding the top panel.
Screw in directly nail on holes of L bracket for wood-surfaces.
On concrete surface, a drill is required to put in tox case first, then screw in nail.
3. For ceiling mounted panels (or if inside a cove), wood rod can directly be screwed in. No need for an L-bracket.

OPTIONAL

4. Install cord brackets on any side of panels.
Cord brackets are where cords can be coiled when panel is raised.
5. Install ground brackets on the ground or sides of panel.
Ground brackets keep the panel in placed during strong winds.
Additional string could be attached at hem of panel for the ground brackets.

HOW TO OPERATE

1. To move to desired length, simply pull-out cords.
2. To lock, tie cords at cord brackets or any nearby post.

CARE AND MAINTENANCE

1. Gently bring down and raise bamboo panels.
Never drag as this will put weight and pressure on top mounting.
2. Raise panels during times of storms (signal number 3) or strong winds.
3. Bring down panels at the end of a heavy down pour to dry.
Accumulated moisture or water in the inner sides of the roll ca or weaving.
4. Remove obstructions such as branches of trees, fallen leaves or other sharp objects near the panels. These may puncture the sticks or weaken the strands.
5. Protect from molds and fungi by brushing up with Leadrite 25 Fungicide Wood Preservative or Woodtec 2.5 EC once a year.